

TOLLERANZE PER FORI																																												
Ø DA (mm)	A Ø (mm)	A9	A11	B9	B11	C9	C11	D9	D10	D11	E8	E9	F7	F8	F9	G6	G7	H6	H7	H8	H9	H10	H11	H13	J6	J7	J8	K6	K7	K8	M6	M7	M8	N6	N7	N8	P6	P7	R7	R8	S7			
2,99	6																																											
6	10																																											
10	18																																											
18	30																																											
30	50																																											
50	500																																											

TOLLERANZE PER ALBERI																																												
Ø DA (mm)	A Ø (mm)	a9	a11	b9	b11	c9	c11	d9	d10	d11	e7	e8	e9	f6	f7	f8	g5	g6	g7	h5	h6	h7	h8	h9	h10	h11	j5	j6	j7	k5	k6	k7	m5	m6	n5	n6	p5	p6	p7	r6	s6			
2,99	6																																											
6	18																																											
18	30																																											
30	50																																											
50	180																																											
180	500																																											

 Process available

 Process not available